NEMESIS
DELAY

Internal and External Control Options

	Tap Tempo	Preset Up	Preset Down	Self-Oscillation /Runaway	Parameter	Hold
Internal Tap Switch	Yes	Yes (Hold when bypassed)	N/A	N/A	N/A	Yes (Hold when Engaged)
Dual Tap Switch (3rd Party)	Set to Switch Select in Nemesis Updater Software	Set to Switch Select in Nemesis Updater Software	Set to Switch Select in Nemesis Updater Software	Set to EXP Map to Feedback	Set to EXP Map to Parameter	Set to Switch Select in Nemesis Updater Software
3rd Party & SA Tap Switch 1/4"	Set to Switch Select in Nemesis Updater Software	Set to Switch Select in Nemesis Updater Software	Set to Switch Select in Nemesis Updater Software	Set to EXP Map to Feedback	Set to EXP Map to Parameter	Set to Switch Select in Nemesis Updater Software
SA Tap Switch 1/8"	Enable in Neuro App or Nemesis Updater Software	N/A	N/A	Enable and Map to Feedback	Enable and Map to Parameter	N/A
Exp. 1/4"	Set to Switch Select in Nemesis Updater Software	Set to Switch Select in Nemesis Updater Software	Set to Switch Select in Nemesis Updater Software	Set to EXP Map to Feedback	Set to EXP Map to Parameter	Set to Switch Select in Nemesis Updater Software
Exp. 1/8"	Enable in Neuro App or Nemesis Updater Software	N/A	N/A	Enable and Map to Feedback	Enable and Map to Parameter	N/A
Soleman	Yes	Yes	Yes	Yes	Yes	Yes