

NEMESIS

DELAY

Control Options Guide

	Tap Tempo	Preset Up	Preset Down	Self-Oscillation /Runaway	Parameter	Hold
On-Board Tap Switch	Yes	Yes (Hold when bypassed)	N/A	N/A	N/A	Yes (Hold when Engaged)
Dual Tap Switch (3rd Party)	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to EXP. ² Map to Feedback.	Set to EXP. ² Map to Parameter.	Set to Switch. ¹ Enable in Neuro Desktop Editor.
3rd Party & SA Tap Switch 1/4"	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to EXP. ² Map to Feedback.	Set to EXP. ² Map to Parameter.	Set to Switch. ¹ Enable in Neuro Desktop Editor.
SA Tap Switch 1/8"	Enable in Neuro App or Neuro Desktop Editor ³	N/A	N/A	Enable and Map to Feedback ²	Enable and Map to Parameter ²	N/A
Exp. 1/4"	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to Switch. ¹ Enable in Neuro Desktop Editor.	Set to EXP. ² Map to Feedback.	Set to EXP. ² Map to Parameter.	Set to Switch. ¹ Enable in Neuro Desktop Editor.
Exp. 1/8"	Enable in Neuro App or Neuro Desktop Editor ³	N/A	N/A	Enable and Map to Feedback ²	Enable and Map to Parameter ²	N/A
Soleman	Yes	Yes	Yes	Yes	Yes	Yes

1 Set the "Pedal In" hardware switch on the top side of the Nemesis to "Switch." Run the Neuro Desktop Editor, and connect the Nemesis via USB. Select the gear icon next to "Nemesis Delay" and select your preferred parameter under, "Ext. Footswitch 1 Function."

2 Set the "Pedal In" hardware switch on the top side of the Nemesis to "Expression." Press the "Control Input" button so that the top right LED is lit. Hold down the "Control Input" button until the top right LED blinks constantly. Press your external footswitch, or move your expression pedal over your desired range of motion. Press the On/Off footswitch. Set the min/max value(s) of your desired parameter(s). Press the On/Off footswitch. Set the max/min value(s) of your desired parameter(s). Press the On/Off footswitch.

3 Neuro App: Connect your mobile device to the Nemesis' Input 2 port with the provided "Neuro Cable." In the Neuro App, select Nemesis // Hardware Options // Enable External Tap Tempo Switch. Note: Hardware Options are retained by your pedal, but not your mobile device.

Neuro Desktop Editor: Run the Neuro Desktop Editor, and connect the Nemesis via USB. Select the gear icon next to "Nemesis Delay" and enable "Use Control Input for External Switch."